

**INSTALLATION, OPERATION and  
MAINTENANCE MANUAL**

**Inverted Bucket Steam Trap  
MODEL: ESU5**



**MIYAWAKI INC.**

Osaka, Japan

**Headquarter:**  
MIYAWAKI Inc.  
2-1-30, Tagawakita, Yodogawa-ku  
Osaka 532-0021  
Japan  
Tel.: + 81-6-6302-5549  
Fax: + 81-6-6302-5595  
e-mail: export@miyawaki.net

**Affiliated Company:**  
MIYAWAKI GmbH  
Birnbaumsmühle 65  
15234 Frankfurt (Oder)  
Germany  
Tel.: + 49-335-4007-0097  
Fax: + 49-335-4000-122  
e-mail: info@miyawaki.de


## SAFETY INSTRUCTION

Prior to using the model ESU5 read this manual thoroughly to understand the correct handling and operating procedure.

The manual should be used by experienced personnel as a guide to the installation and maintenance of the Steam Traps.

We ask you to contact MIYAWAKI or its local representative if further information is required.

### 1. Dimensions and Technical Specification



Model	Connec-tions	Size	Max. Oper. Pressure	Max. Oper. Temperature	Dimensions mm (inch)			Weight		
			MPa (psig)	°C (°F)	L	H <sub>1</sub>	H <sub>2</sub>	W	kg	lb
ESU5	screwed Rc, NPT	1/2"	see Table 1	350 (662)	103 (4.1)	57 (2.2)	69 (2.7)	75 (3.0)	1,9	4.2
		3/4"			105 (4.1)				2,0	4.4
		1"			109 (4.3)				2,1	4.6
ESU5F	flanged JIS, ANSI, DIN	1/2"	see Table 1	350 (662)	175 (6.9)	57 (2.2)	69 (2.7)	75 (3.0)	3,5	7.7
		3/4"			195 (7.7)				3,7	8.2
		1"			215 (8.5)				4,1	9.0

Available Types acc. to Max. Oper. Pressure (PMO):

Type	Max. Oper. Pressure PMO	
	MPa	psig
ESU5(F)-3	0,3	43
ESU5(F)-7	0,7	100
ESU5(F)-11	1,1	160
ESU5(F)-16	1,6	230
ESU5(F)-21	2,1	305


## 2. Installation

<b>CAUTION</b>	Before installing the trap, always blow down the piping that leads to the trap's inlet.
----------------	---


<b>CAUTION</b>	The “Bell Mighty” inverted bucket steam trap Model ES can only be installed horizontally.
----------------	---

- A. Install the trap according to the direction of the arrow on the body.
- B. Install the trap at the lowest point of the steam using equipment to be drained.
- C. Install the trap so that the condensate will flow naturally into the trap.
- D. When recovering the condensate, the outlet branch line should be piped from the steam trap as shown in drawing A.  
It is recommended to install a check valve on the downstream side of the trap.
- E. If the trap is installed higher than the steam using equipment, use a lift fitting as shown in drawing B for better performance.
- F. If the trap is used for draining a cylinder dryer, please, install it lower than the lowest point of the cylinder and minimize the horizontal piping.  
Do not insulate the piping.
- G. The trap should be installed for easy maintenance.
- H. Upon start up inspect the following:
  1. Eventual leakage from the sealing of the Body (1) and the Cover (2). If the trap is leaking retighten the cover bolts (20) evenly crosswise.
  2. Eventual leakage from the Plugs (3) or (4). If the trap is leaking retighten the plugs.

Drawing A



Drawing B



### 3. Trouble-shooting

The steam trap should be checked for proper operation at least once a year.

The inverted bucket steam trap is operating intermittently, i.e. it will discharge the condensate and close at certain cycles.

Improper operations will be:

- No discharge
- Continuous discharge of condensate or steam.

Problem	Reason
The trap is not discharging. The trap is cold.	A. The inlet valve is closed. B. The operating pressure is too high. Check the operating conditions of the trap. If necessary reduce the inlet pressure or change the valve (No. 6) and the valve seat (No. 5) according to the higher operating pressure. C. The screen of the capsule (11) is plugged. D. The air vent (hole in the bucket) is plugged. E. The valve seat is plugged.
The trap is not discharging. The trap is hot.	A. No Condensate is flowing to the trap. - The by-pass valve or flange upstream are leaking. - In case of cylinder dryers the siphon tube is damaged or broken. - A vacuum had been created at the upstream piping. Install a vacuum breaker upstream.
The Trap is discharging continuously condensate.	A. The capacity of the trap is too low.
The trap is blowing through steam.	A. Loss of prime The ES model has a self-priming effect. If a normal amount of condensate is flowing into the trap, it will self-prime. B. Scale is lodged between the valve and the valve seat. C. The valve or the valve seat are damaged.


### 4. Maintenance, Disassembling and Assembling

**WARNING**

Before disassembling a steam trap be sure to close the valves in both supply and discharge lines, reduce the pressure inside the trap to atmospheric pressure, and allow the trap to cool before opening it.

For cleaning purposes or for changing parts perform the following steps:

- A. Remove the Cover Bolts (20). Take off the Cover (2) together with all internal parts ( Valve Seat (5), Valve (6), Valve Holder (7), Pin (8), Bucket (9), Eye Bolt (10), Eye Bolt Pin (12), Lever (13), Bracket (14), Pin (15), Set Bolt (16) as shown in drawing C).



Drawing C

- B. Take off the Pin (15), unscrew the Set Bolt (16) and the Valve Seat (5) with a wrench.
- C. Take off the Pin (8). The Valve (6) and the Valve Holder (7) can be removed from the Lever (13) (detailed drawing see point 5).
- D. Take off the split pin and Eye Bolt Pin (12) (see point 5).  
You can take off the bucket (9) .
- E. Take off the capsule (11) and clean it.
- F. Clean and inspect all parts. Replace any that are worn or damaged.  
Assemble in the opposite way as disassembling.

Especially thoroughly check the Valve (6), the Valve Seat (5) and the Valve Holder (7).

When there will be the necessity to replace the Valve (6) and/or the Valve Seat (5) always replace both together as they are lapped together in the factory.

<b>CAUTION</b>	When reassembling always replace the Cover Gasket (21) by a new one.
----------------	--

<b>CAUTION</b>	Tighten the Cover Bolts (20) evenly crosswise.
----------------	--

### Wrench Sizes and Torques

Parts Number	Parts Name	Wrench Size	Torque
20	Cover Bolt	13 mm	210 kgf·cm (21 Nm)
16	Set Bolt	13 mm	110 kgf·cm (11 Nm)
5	Valve Seat	14 mm	300 kgf·cm (30 Nm)

## 5. Details and Spare Parts List

